


 Отвод сегментный  
5 - 45°

DN	SDR17	SDR11
40	119	183
50	163	252
63	265	381
75	271	393
90	293	440
110	402	581
125	530	770
140	680	990
160	730	1211
180	950	1390
200	1231	1780
225	1650	2365
250	2500	3680
280	3255	4711
315	4090	6100
355	5540	8172
400	7491	11555
450	10924	15780
500	14950	22300
560	20500	31049
630	26000	44000


 Отвод сегментный  
50 - 90°

SDR17	SDR11
225	331
261	400
330	555
386	570
422	641
513	725
782	1170
976	1430
1057	1580
1520	2250
1780	2570
2440	3640
3516	5090
4290	6190
5600	8738
8318	12739
11680	17140
14850	22400
20877	31001
30012	44354
38700	64942




Крестовина 90°

DN	SDR17	SDR11
63	384	565
75	541	782
90	708	1036
110	851	1236
125	1066	1581
140	1340	1967
160	1646	2434
180	1944	2870
200	2397	3541
225	3043	4762
250	4160	6126
280	5870	8635
315	7127	12355
355	10229	17108
400	15878	23476
450	20130	31495
500	26967	42923
560	40542	59708
630	51304	80478


 Тройник 90°  
сегментный

SDR17	SDR11
384	699
541	969
708	1282
851	1531
1066	1957
1340	2436
1646	3014
2361	3554
3321	4384
4474	5563
5885	7585
7976	10691
11329	13033
18611	18597
26223	29066
36036	36788
52930	49208
71064	73924
93911	94001


 Тройник  
сегментный 45°

DN	SDR17	SDR11
63	323	519
75	380	599
90	555	858
110	978	1489
125	1347	2057
140	1850	2779
160	2393	3598
180	3238	4840
200	5290	7728
225	6892	10089
250	9119	13345
280	11317	16563
315	15369	22792